Government of India Ministry of Health and Family Welfare Directorate General of Health Services [Emergency Medical Relief]

Guidelines for prevention of transmission and disinfection of hotels/lodging facility where suspect/confirmed COVID-19 cases have housed.

Scope: This document aims to provide interim guidance about the environmental cleaning /decontamination in hotels/lodging facility where persons with potential exposure to COVID-19 have housed.

The causative agent involved in the current outbreaks of COVID -19 acute respiratory disease, the SARS-CoV 2 is an enveloped RNA virus. Coronaviruses are transmitted in most instances through large respiratory droplets and contact transmission, but other modes of transmission have also been proposed worldwide.

The following guidelines should be followed:

#### Hotel Reception

Hotel staff at the reception should be well versed in hand hygiene, respiratory hygiene, and protocols to be followed if a guest develops symptoms. (Annexure 1, 2)

#### All Guests:

- Ask guests whether they have resided in or history of travel to an affected area or contact with a known case in the past 14 days. (As per travel advisory on web site of MoHFW)
- 2. Advise to observe good personal hygiene, especially hand hygiene and respiratory (cough and sneeze) hygiene (Annexure 1 & 2).
- 3. Provide alcohol-based handrub containing 70% Alcohol to guests in public areas (Reception, lobby, Restaurants. Conference area, Business centre, Gym etc)
- 4. Provide surgical masks to guests if they develop respiratory symptoms. (Annexure 3-Guidelines for use of mask)

# For guests with history of travel to or resided in the affected areas:

- 1. Provide information pamphlet upon check-in or visit https://mohfw.gov.in/node/4904
- 2. Guest(s) is/are advised to stay in the room if feeling unwell, wear a surgical mask and call hotel operator at once for assistance.
- 3. Encourage person with respiratory symptoms to sit away from others ideally at a distance of  $1-2\,\mathrm{m}$

# Handling sick guest(s) with history of travel to or resided in the affected areas:

1. Advise and assist sick guest(s) who develop symptoms (fever, cough, sore throat, breathlessness, etc.) within 14 days after return from the affected areas, call control

room/identified hospital and inform about the condition of sick guest(s). Arrange for ambulance and consultation in Emergency Department.

2. Before seeking medical care:

- Advice sick guest(s) to stay in his/her room and put on a surgical mask.
- Group and relocate any asymptomatic roommate(s) to another room, and they should stay in the relocated room(s).
- Minimize contact with sick guest(s), and other guest(s) travelling along with the sick guest(s).
- Staff should put on PPE while interacting with/ shifting sick guest.
- Staff should be aware of the symptoms, and should report immediately if they develop any symptoms and should be immediately referred to an identified healthcare facility.

Environmental cleaning: Due to the potential survival of the virus in the environment for about a week, the premises and potentially contaminated areas should be cleaned before their reuse, using products containing antimicrobial agents known to be effective against coronaviruses.

Although there is lack of specific evidence for their effectiveness against SARS-CoV 2 virus, cleaning with water and household detergents and use of common disinfectant products should be sufficient for general precautionary cleaning. Tests carried out using SARS-CoV showed that sodium hypochlorite is effective.

These guidelines provide guidance for environmental cleaning in hotels/lodging facility housing people exposed/ potential exposure to SARS-CoV 2.

## Personal Protective Equipment (PPE):

Wear appropriate PPE while carrying out cleaning and disinfection work.

- Wear disposable gloves (heavy duty), disposable long-sleeved gowns, eye goggles or a face shield, and an N95 mask. (Annexure 4: Donning and Doffing PPE)
- 2. Avoid touching the eyes, nose and mouth
- Gloves should be removed and discarded if they become soiled or damaged, and a new pair worn.
- All other disposable PPE should be removed and discarded after cleaning activities are completed.
- PPE should be discarded in a thick plastic bag, sealed, labelled and sent to the nearest health facility for discarding as an infectious waste.
- Hands should be washed with soap and water immediately after each piece of PPE is removed, following completion of cleaning.
- The cleaning crew should be aware of the symptoms, and should report immediately if they develop symptoms and should be immediately referred to an identified healthcare facility.

N.B.: Masks are effective if worn according to instructions and properly fitted. Masks should be discarded and changed if they become physically damaged or spaked. (Annexure 3)

# Lodging area

Area/Items	ttem/Equipment	Process	Method/procedure*	
General cleaning	Detergent and warm water Mop Two buckets Clean utility gloves Hand mops 1% freshly prepared sodium Hypochlorite	Daily mopping Floors Thorough washing	Scrub floors with hot water and detergent with using minimal water. (Do not pour the water.)     Clean with plain water.     Allow to dry     Mop with 1% Sodium     Hypochlorits     Notes Recommend general cleaning procedure should be done twice a day	
Lockers, tables, cupboard, wardrobes, benches, shelves and cots	Damp duster with 1% Sodium Hypochlorite	Dump dusting	Damp dust with 1% Sodium     Hypachlorite	
Railings	Detergent/ Sanitizer-hot water, sodium hypochlorite 1% Three small buckets/ or big bowls One with plain water One with detergent solution One for sodium hypochlorite 1%	Delty dusting	Damp dist with warm water and detergent followed by disinfection with sodium hypochlorite	
Mirrors and Glass	Warm water Detergent water/ cleaning solution Damp cloth Wiper	Cleaning	<ul> <li>Using warm water and a small quantity of detergent and using a damp cloth, wipe over the mirror and surround, then using a dry lint-free cloth, buff the mirror and glass to a clean dry finish.</li> </ul>	
Sluice room Stainless steel/ Any other sink	Powder cleanser Detergent powder Wiper Cloth	Cleaning	Sinks are to be cleaned with a powder cleanser. First wet the sink. Sprinkle on a little powder cleanser and work around the surface with a cloth, include the plughole. Do not use the powder cleanser on dry sink. After removing spillage and any stains, flush away with running water. Wipe down the surface of the sink.	
Telephone	70% alcohol wipes	General cleaning	Damp dust with 70% alcohol wipes     Pay special attention to the ear and mouth piece.	
Deska	Damp cloth in 1% Sodium Hypochlorite /70% alcohol wipes Furniture polish	Damp cleaning	Wipe top sides and draw handles with a damp cloth. Pen holder etc. to be wiped with the damp cloth with 1% Sodium Hypochlorite or wipe with 70% alcohol wipes.	

Chairs (Vinyi)	Warm water and detergent 1% sodium . hypochlorite	Cleaning	Wipe down with warm water and detergent Wipe with 1% sodium hypochlorite, Remové any marks under arms and seat.	
Furniture and littings	1% Sodium Hypochlorite Rag piece/duster	Cleaning	<ul> <li>Using 1% Sodium Hypechlorite, damp dust all furniture and fittings, including chairs, stools, beds, tables, cupboards, wardrobes, lockers, trolleys, benches, shelves and storage racks, waster bins, fire extinguishers, televisions windowsills.</li> </ul>	
Bed tables, bedside lockers	1% Sodium Hypochlorite Rag pieca/duster	Cleaning	Wipe down over bed table. Wipe top and underneath base and stand, using 1% addium hypochlorite. Wipe down the bedside. Remove marks from fronts of draws and sides	
Light switches and over-bed lights	1% Sodium Hypochlorite /70% Alcohol Rag plece/duste r	Cleaning	Light switches to be cleaned of dust, spots and finger marks. Clean with a damp cloth (never wet)     Over-bed lighting to be damp dusted, Clean with damp cloth or alcohol wipes.	
Curtains Linen, quilts, covers and Towels	Water Detergent Washing machine	Washing	<ul> <li>Using hot water cycle wash with detergent or disinfectant in water at 70°C for at least 25 minutes.</li> </ul>	
White clothes	Sodium hypochlorite 1% Tap water	Washing	Should be washed under running water and soaked in 1% sodium hypochlarite for 20minutes. Note: PPE should be worn while washing soiled linen.	
Mattress and pillow covers (cloth)	Tap water	Washing	Mattress and pillows should be covered with a reusable mattress cover.'     It should be changed for each guest and when soiled sent to the laundry according to schedule and washed as linen.	
Mattress/ Pillow with rexin cover Normal/ without rexin	Sodium hypochlorite 1 % Sunlight	Terminal Damp dusting and cleaning Drying in aunlight	If with rexin cover, can be cleaned with 1% sodium hypochlorite before use for next guest  If routine mattress, dry it in bright sunlight for 1-2 days before using for next guest.	
Water jars	Vim powder Soap and water	Cleaning	Recommended boiled water for drinking     Water jars should be scrubbed/ cleaned with soap and water and boiled water before filling with water.	



<sup>\*</sup>Always use freshly prepared 1% sodium hypochlorite. Avoid flushing down the used sodium hypochlorite in the sanitary sewer. Discard in the mud pits.

\*70% Alcohol/ Chloroxylenol (4.5-5.5%)/ Benzalkonium Chloride can be used as per manufacturer's instructions to wipe down surfaces where the use of bleach is not suitable, e.g. metal.

Cleaning of toilets

Areas	Agents / Toilet cleaner*	Procedure	
Tollet pot/ commode	Sodium hypochlorite 1%/ Soap powder / long handle angular brush	Inside of tolet pot/commode:     Scrub with the recommended agents and the long handle angular brush.     Outside: Clean with recommended agents; use a scrubber.	
Lid/commode	Nylon scrubber and soap powder 1% Sodium Hypochlorite	Wot and scrub with soap powder and the nylon scrubber inside and outside.     Wipe with 1% Sodium Hypochlorite	
Collet Roor Scap powder and scrubbing brush/ nylon broom 1% Sodium Hypochlorite		Scrub floor with soap powder and the scrubbing brush     Wash with water     Use sodium hypochlorite1% dilution	
Sink	Soap powder and nylon scrubber 1% Sodium Hypochlorite	Scrub with the nylon scrubber.     Wips with 1% Sodium Hypochlorite	
Showers area / Warm water Taps and fittings Detergent powder Nylon Scrubber 1% Sodium Hypochlorite/ 70% alcohol		Thoroughly scrub the floorartiles with warm water and detergent Wipe over tapa and fittings with a damp cloth and detergent. Care should be taken to clean the underside of taps and fittings. Wipe with 1% Sodium Hypochlorita/ 70% alcohol	
Soap dispensers Detergent and water		Daily dusting     Should be cleaned weekly with detergent and water and dried.	

\*Always use freshly prepared 1% sodium hypochlorite. Avoid flushing down the used sodium hypochlorite in the sanitary sewer. Discard in the mud pits.

\*70% Alcohol/ Chloroxylenol (4.5-5.5%)/ Benzalkonium Chloride can be used as per manufacturer's instructions to wipe down surfaces where the use of bleach is not suitable, e.g. metal.

- Cleaning and disinfection of public area such as lifts, elevators, telephones, washrooms and lobby with disinfectant 1% sodium hypochlorite every six hours or earlier if a positive/suspect case is detected; Special attention should be paid to frequently touched areas like walls, lift buttons, rails, door handles, arm rests, tables, switches of light and air control keyboards.
- Clean and disinfect the air-conditioning system at least once per week
- Switch off the central air condition in the room in the which there is a suspect case.
- To prevent cross contamination, discard cleaning material made of cloth (mop and wiping cloth) in appropriate bags after cleaning and disinfecting. Wear new pair of gloves and fasten the bag.
- Disinfect all cleaning equipment after use and before using in other area
- Disinfect buckets by soaking in bleach solution or rinse in hot water

Table 1: Guidelines for Preparation of 1% sodium hypochlorite solution

Product	Available chlorine	1percent	
Sodium hypochlorite – liquid bleach	3.5%	1 part bleach to 2.5 parts water	
Sodium hypochlorite – liquid	5%	1 part bleach to 4 parts water	
NaDCC (sodium dichloro- isocyanurate) – powder	60%	17 grams to 1 litre water	
NaDCC (1.5 g/ tablet) - tablets	60%	11 tablets to 1 litre water	
Chloramine – powder	25%	80 g to 1 litre water	
Bleaching powder	70%	7g g to 1 litre water	
Any other	As per manufacturer's Instructions		

Fogging with Hydrogen peroxide with silver nitrate (such as Ecoshield, Envishield, Radix Sil 10, Silvox, etc (in alphabetical order):

- Equipment: Portable 4-Direction Fogger/ Fogger/Mobile fogger
- Solution: Stabilized hydrogen peroxide 11% w/v with 0.01% w/v diluted silver nitrate solution.
- For surface disinfection: 10% v/v solution in de-ionized water with contact time of 60 min.
- For fogging: 1 litre of 20% v/v solution /1000 cu. ft of space in 60 min. (or as per manufactures instructions)

#### References:

- Van Doremalen N, Bushmaker T, Munster VJ. Stability of Middle East respiratory syndrome coronavirus (MERS-CoV) under different environmental conditions. Euro surveillance: bulletin Europeen sur les maladies transmissibles = European communicable disease bulletin. 2013 Sep 19;18(38).
- Otter JA, Donskey C, Yezli S, Douthwaite S, Goldenberg SD, Weber DJ. Transmission of SARS and MERS coronaviruses and influenza virus in healthcare settings: the possible role of dry surface contamination. The Journal of hospital infection. 2016 Mar;92(3):235-50.
- Lai MY, Cheng PK, Lim WW. Survival of severe acute respiratory syndrome coronavirus. Clinical infectious diseases: an official publication of the Infectious Diseases Society of America. 2005 Oct 1;41(7):e67-71.
- Hulkower RL, Casanova LM, Rutala WA, Weber DJ, Sobsey MD. Inactivation of surrogate coronaviruses on hard surfaces by health care germicides. American journal of infection control. 2011;39(5):401-7.
- 5. National Guidelines for Infection Prevention and Control In Healthcare Facilities, MOHFW, Gol
- Ministry of Health (MOH) and the National Environment Agency (NEA), of Singapore, Interim Guidelines for Environmental Cleaning and Disinfection of Areas Exposed to Confirmed Case(s) of COVID-19 in Non-Healthcare Premises. 28Feb 2020
- 7. Guidelines for disinfection of quarantine facility for coronavirus infection. NCDC. Delhi Feb 2020.
- Interim Guidelines for Environmental Cleaning and Disinfection of Areas Exposed to Confirmed Case(s) of COVID-19 in Non-Healthcare Premises. The National Environment Agency. Singapore. Feb 28, 2020
- D. Mosci, G.W. Marmo, L. Sciolino et al Automatic environment Agency. Singapore. Feb 28, 2020 peroxide and silver ions versus manual environmental disinfection with hydrogen peroxide and silver ions versus manual environmental disinfection with sodium hypochlorite: a multicentre randomized before-and-after trial. J of Hosp Infection. Oct 2017, Volume 97, Issue 2, 175-179. DOI: https://doi.org/10.1016/j.jhin.2017.06.010

-6-

# Hand-washing technique with soap and water



Wet hands with sware



Apply enough soa to cover all hand surfaces




Rub hands palm



Rub back of each hand with palm of other hand with fingers interlaced



Rub palm to palm with



Rub with back of fingers to opposing palms with fingers interlocked



Rub each thumb clasped in opposite hand using a rotational movement




Rub tips of fingers in opposite palm in a circular motion



Rub each wrist with opposite hand



Rinse hands



Use elbow to



Dry thoroughly with a single-use towel




Hand washing should take 15-30 seconds

Steps from 2-9 are same while using alcohol-based hand rub

# Annexure 2: Respiratory Hygiene

- Cover mouth and nose when coughing or sneezing or if tissue not immediately available, in the flexed elbow.
- Use tissue paper to contain respiratory secretions and dispose it promptly in lid dustbin
- Perform hand hygiene after hands have been in contact with the respiratory secretions




#### Annexure 3: Guidelines for use of mask

The correct procedure of wearing triple layer surgical mask:

- 1. Perform hand hygiene
- 2. Unfold the pleats; make sure that they are facing down.
- 3. Place over nose, mouth and chin.
- 4. Fit flexible nose piece over nose bridge.
- Secure with tie strings (upper string to be tied on top of head above the ears –lower string at the back of the neck.)
- 6. Ensure there are no gaps on either side of the mask, adjust to fit.
- 7. Do not let the mask hanging from the neck.
- 8. Change the mask after six hours or as soon as they become wet.
- 9. Disposable masks are never to be reused and should be disposed off.
- 10. While removing the mask great care must be taken not to touch the potentially infected outer surface of the mask
- To remove mask first until the string below and then the string above and handle the mask using the upper strings.
- Disposal of used masks Used mask should be considered as potentially infected medical waste.
   Discard the mask in a closed bin immediately after use.

# Annexure 4: Donning & Doffing of PPE

Donning & Doffing procedures should be diligently & carefully followed as given below.



- Keep hands away from face
- · Limit surfaces touched
- Change gloves when torn or heavily contaminated
- Perform Hand Hygiene

# HOW TO SAFELY REMOVE PERSONAL PROTECTIVE EQUIPMENT (PPE) **EXAMPLE 1**

There are a variety of ways to safely remove PPE without contaminating your clothing, skin, or mucous membranes with potentially influctious materials. Here is one example. Remove all PPE before exiting the patient room except a respirator, if wom. Remove the respirator after leaving the patient room and closing the door. Remove PPE in the following sequence:

- . Outside of gloves are contaminated?
- If your hands get contaminated during glove removal, immediately washyour hands or use an alcohol-based hand sandtizer
- . Using a gloved hand, grasp the palm area of the other gloved hand and peel off first glove
- Hold removed glove in gloved hand
   Side lingers of ungloved hand under remaining glove at wrist and peel off second glove over first glove
- · Discard gloves in a waste container

# 2. GOGGLES OR FACE SHIELD

- · Outside of goggles or face shield are contaminated!
- If your hands get contaminated during google or face shield removal, immediately washyour hands or use an alcohol-based hand sanitizer
- · Remove goggles or face shield from the back by lifting head band or ear pieces
- . If the item is reusable, place in designated receptable for reprocessing. Otherwise, discard in a waste container

## 3. GOWN

- Gown front and slagues are contaminated!
- if your hands get contaminated during gown removal, immediately wash your hands or use an alcohol-based hand sanitizer
- Obfasten gown ties, taking care that sleeves don't contact your body when reaching for ties
- · Pull gowo away from neck and shoulders, touching inside of gown only
- Turn goven inside out
- . Fold or rolf into a bundle and discard in a waste container

# 4. MASK OR RESPIRATOR

- Front of mask/sespk ator is contaminated DO NOT TOUCH!
- If your hands get contaminated during mask/sepirator removal, immediately wash your hands or use an elcehol-based hand sanitizer
- Grasp bottom ties or elastics of the mask/respirator, then the ones at the top, and remove without touching the front
- . Discard in a wasto container

